

# Instyle Colourflex Dmx Driver

The power cable of the unit should be connected to an Instyle 12v/12v transformer




There are two dmx control sockets

The two sockets are for connection of DMX (in and link through) or for master slave linking of units.

**Warning:** Although this unit uses similar connectors to a computer network, it is not compatible. Network equipment may be damaged if you connect this unit to a computer network.

## Dip Switch settings

Linking to INSTYLE Wall Controller 9 on (9 up rest down)  
Auto colour scroll All off (all down)



## DMX / RJ45 Connections

- Pin 1 : Data + Orange and White
- Pin 2 : Data – Orange
- Pin7 : Common Brown and white
- Pin 8 : Common Brown